

No Sound from Creative Speakers

Keywords / Key Phrases: no sound, X-Fi Titanium

Please ensure that the speakers are connected properly to the sound card line out jacks. You should be able to get audio output from your speakers when you perform a speaker test or when you playback an audio file.

Windows Vista Operating System:

1. Please ensure that sound card is set as the default playback device on the "Sound and Audio Devices" in the **Control Panel**.
2. To verify if the sound card is installed and functioning correctly on **Device Manager**:
 - Go to the **Device Manager**
 - Expand the "Sound, video & game controller"
 - Look for the Creative sound card listed as "SB X-Fi" or similar name
 - Ensure that the sound card is working properly under Properties and without any error or exclamation mark

Windows XP Operating System:

1. Please ensure that sound card is set as the default playback device on the "Sound" in the **Control Panel**.
2. To verify if the sound card is installed and functioning correctly on **Device Manager**:
 - Go to the **Device Manager**
 - Expand the "Sound, video & game controller"
 - Look for the Creative sound card listed as "SB X-Fi" or similar name
 - Ensure that the sound card is working properly under Properties and without any error or exclamation mark

If the issue persists, try to install the sound card on another computer if available. This will determine if the sound card is working properly.

Further Suggestions

[SID 5035](#) - Connecting Speakers to a Sound Card

Last updated: August 02, 2010