

Creative applications not Working

Keywords / Key Phrases: creative application, not working, not functioning, launching, errors

1. The Creative application is not working and this could be due to corruption or missing files. It is recommended that you repair the application from the Installation CD if the applications were installed from the CD.
2. Insert the sound card installation CD into your optical drive. Following the instructions, you will come to a page where the options would be **Add/Remove**, **Repair** and **Uninstall**. At this point, select **Repair** and in the checklist select only Audio Driver to repair the driver in case it is corrupted.
3. If the issue persists, download the latest updates by clicking on the **Downloads** link at the top right corner of this page under **Quick Links** and re-install it for your Sound Card.

Last updated: July 13rd, 2009