

Creative Audio Control Panel Settings Return to Default after System Reboot

Keywords / Key Phrases: creative audio control panel, settings back to default, creative audio control panel settings reset

Perform the following steps if the settings which you have configured in Creative Audio Control Panel resets to default after your computer reboots.

1. Uninstall all Creative related applications / hardware
2. Uninstall your sound device via the device manager
3. Reboot your computer into safe mode

Windows XP / Vista / 7: To get into the Windows Vista and Windows 7 Safe Mode, as the computer is booting, press and hold your "F8 Key" which should bring up the "Windows Advanced Options Menu". Use your arrow keys to move to "Safe Mode" and press your Enter key.

4. Remove all Creative folders and ensure that no Creative applications exist in the pc.
5. Reboot your system into normal mode and reinstall your device. Next, download and install the latest driver for your sound device on your operating system in support.creative.com

Last updated: September 09, 2011