

## Missing Dolby Digital Live Logo in the Console Launcher

**Keywords / Key Phrases:** missing ddl, missing dolby digital live logo, dolby digital live logo

### Summary:

- ✓ Checking the activation of the Dolby Digital Live for Creative sound cards

Dolby Digital Live is a technology which is new to Creative sound cards. It needs to be activated prior usage. If the Dolby Digital Live Logo is missing from the Entertainment Mode, either the Activation did not work properly or the Software has not been activated at all.



To check if the Activation was successful:

1. Click on the "Start" button and access the start menu
2. Choose the option "DDL License Activation"
3. If the Activation was completed successfully the Activation Wizard will show an Information "Activation successful."
4. If the Activation was not completed the Activation Wizard will launch. Please proceed to install

## Note

Requirements for a successful Activation:

- A valid Key. The key can be found on the Leaflet for the Installation CD.
- Access to the Internet. Remember that Antivirus and/or Firewall Applications may block the Internet Access.

---

Last updated: July 10th, 2009