

Sound from Casing front audio Panel but not from the Sound Card

Keywords / Key Phrases: front front audio panel, front casing, audio output

As you are getting sound output from the casing front audio panel instead of coming from the sound card, it is most likely that the default audio device is set to the onboard audio device.

Windows Vista Operating System:

To verify the default audio device, please refer to the **Audio** option in the **Control Panel**.

1. Click on the **Playback** tab.
2. Ensure that the default Speaker points to the Creative sound card instead of the onboard audio device.
3. If not, click on the Speaker pointing to the Creative sound card and click on the Set Default button to make it the default audio device.

Windows XP Operating System:

To verify the default audio device, please refer to the **Sound and Audio Devices** in the **Control Panel**.

1. Click on the **Audio** tab.
2. Ensure that the default device for Sound playback and recording is set to the Creative sound card instead of the onboard audio device.
3. If not, click on the drop-down to select the Creative sound card to make it the default audio device.

Last updated: July 10th, 2009