

No Sound from the Digital Out/Optical Out Jack

Keywords / Key Phrases: no audio, no sound, digital out, optical out, sound card, no sound from the optical and digital out, flexi jack, x-fi

To get sound from the Digital Out jack on your sound card, please make sure the option for the Flexi Jack is set to "Digital Output Only" or "Enable Digital I/O" is checked under Digital I/O icon under Entertainment Mode.

You may refer to the article below for the steps on how to enable this option.

How to Enable SPDIF Out and Digital I/O

<http://support.creative.com/kb/ShowArticle.aspx?sid=64440>

Last updated: June 20th, 2009