

Unable to Select the Microphone from Front Panel

Keywords / Key Phrases: unable to select microphone, front panel

It is recommended that you test the microphone connection to the front I/O drive using Creative Mediasource. Make sure that you have set the record source in the Mediasource to Mic In 2 as it will be different port from the rear connectors.

Also you can verify if the game is able to select the Mic In 2 which is referring to the front I/O drive Mic In connection. You can refer to the software vendor for more support on the configuration of the alternate microphone input from a sound card.

Last updated: July 20th, 2009