

Unable to Switch Back to Default Mode

Keywords / Key Phrases: automode switcher, default mode

If you are having issue with switching back to the default mode after exiting from the games, please ensure that the AutoMode Switcher is being launched at startup by using the steps below. The automode switcher allows the console to toggle between entertainment mode & gaming mode.

1. Launch the AutoMode Switcher
2. Click on Settings
3. Ensure that the "Launch Creative AutoMode Switcher on Windows Startup" is checked

Should the issue persists, please download the latest driver and application from our "downloads" section directly..

Last updated: July 24th, 2009