

## **Changing of Volume in Sound Blaster**

Keywords / Key Phrases: volume, main volume adjustment, change, adjust

To adjust the main volume, you can click on the speaker icon located at the system task bar near the date and time. A volume control pops up and you can adjust the main volume for your audio output.

If you wish to adjust the other volume, such as Line-In/Mic-In or other sources, you will need to launch the Mixer by double-clicking on the speaker icon at the system task bar. From there, you are able to adjust the volume of the individual input or output sources.

Last updated: July 21st, 2009