

Connecting an AV Receiver to a Sound Blaster


Keywords / Key Phrases: connecting av receiver, av receivers

It is strongly recommended that you connect your Sound Blaster to the analog multi-channel inputs instead of digital input if your AV receiver has both digital input as well as analog multi-channel inputs.

If you are going to connect from the Digital Out on your Sound Blaster to the Digital Input on your receiver, you will only receive multi channel audio when you are playing DVD games, or DVD movies, or standalone AC3 files. You will only hear stereo (front left and right channels) when playing MP3, MID, AVI, WAC, or WMA et.

In addition, the DVD-Audio playback is restricted to analog out only. The Digital Out will be automatically muted when you start to play a DVD-Audio file. (DVD Audio is not supported in Windows Vista).

The analog input jacks on some AV receivers may be labeled as DVD input or DVD Multi-channel.



To connect a Sound Blaster card to a multi-channel AV receiver, use a cable similar to the Creative Home Theater cable.



Last updated: July 6th, 2009