

## Graphic Equalizer to replace Bass & Treble

Keywords / Key Phrases: graphic equalizer, bass, treble

As the sound card comes with the Graphic Equalizer, it can control the mid-range and also the bass and treble.

To control the bass, mid-range and treble, please refer to the steps below:

1. In Entertainment mode, select the **Graphic Equalizer**
2. Tick the **Enable EQ** option
3. You can use the 10 bands to control the bass, mid-range and treble in the Graphic Equalizer from the left to right respectively

The 10 band graphic equalizer will be able to configure a better sound as compared to the bass and treble.

Last updated: July 20th, 2009