

Unable to record without the effects in Music Creation Mode

Keywords / Key Phrases: record without effects, no effects

To record without Aux 1 Reverb, Aux 2 Chorus or Aux 3 or 4, simply mute the effects being applied to the recording. To do this look under Master Auxiliary Effects, there should be 4 Mute buttons on the right.

Note that if you see the Mute button being grayed out for Aux 3 and 4, it is likely that no effects have been selected.

Last updated: August 5th, 2009