

How to launch basic Creative Audio Control Panel in Windows 10

Keywords/keyphrases: Windows 10, Audio Control Panel, X-Fi, X-Fi Titanium, Audigy, Live, launch, basic software, metro, default, audio endpoint, properties, Creative


Summary:

- ✓ **Applicable To:** X-Fi, X-Fi XtremeMusic, X-Fi Xtreme Gamer, X-Fi Xtreme Gamer Fatal1ty Professional series, X-Fi Platinum, X-Fi Platinum Fatal1ty Champion series, X-Fi Fatal1ty, X-Fi Elite Pro, X-Fi Xtreme Audio, X-Fi Xtreme Audio PCIe, X-Fi Surround 5.1, X-Fi Surround 5.1 Pro, X-Fi Go! , X-Fi Go! Pro, X-Fi Titanium, X-Fi Titanium Professional Audio, X-Fi Titanium Fatal1ty Professional series, X-Fi Titanium Champion series, X-Fi Titanium HD, Sound Blaster Play!, X-Fi HD, SB Digital Music Premium HD, SB Easy Record, SB Connect, SB MP3+, Live! 24 bit external, Audigy 4, Audigy SE, SB 5.1 VX
- ✓ This article highlights 2 methods of launching basic Creative Audio Control Panel in Windows 10. This article is applicable to those products with Windows 10 support that do not have the graphical software interface.


In this example, X-Fi Titanium is installed for the screen captures.

Method 1:


Click on **All apps** at the Windows Start button.



Look for Creative Audio Control Panel and click on it.




This is the basic Creative Audio Control Panel.




Method 2:


At the Windows search bar, type **Sound** to launch this utility. Then, click on the **Properties** after selecting a default audio endpoint.



Under this **Speaker Properties**, select **Sound Blaster** tab and choose **Settings**.



Here is the summary of launching Creative Audio Control Panel using Method 2.



Last Updated: September 18, 2015