

Error Message when installing Sound Card Console Launcher

Keywords/Keyphrases: audio console, not supported, error, no sound, recording

If you are installing **Console Launcher**, and then you received the error message: "The selected audio device is not supported by the application". And then, there is no sound from the microphone and it doesn't record any sound, even though the microphone is already set as standard; it is likely that Microphone/Line-in settings are not properly configured.

In cases like this, open **Audio Console**, go to **Flexi-jack** tab and ensure that **Microphone/Line-in** is selected.

Last Updated: February 3, 2010