

Sound Fluctuates or Intermittent Sound

Keywords / Key Phrases: intermittent sound, fluctuate, fluctuation

Please check the connection between your sound card and your speakers to make sure there are no loose connections that can result to fluctuating sound.

You can also try other audio sources (MP3, CD, movies) to make sure the file you are listening is not corrupted or damaged.

You can also test your sound card using a working headphone to ensure the fluctuating sound is not caused by the speaker system. Please following the instructions in the article below:

[SID 28515: No sound or poor sound from portable speakers](#)

If issue persists, you may check if the sound card is sharing the same IRQ with other devices installed on your computer. To check this, please refer to the article below:

[SID 2442: IRQ - General Information and Essential Troubleshooting](#)

Last updated: August 17th, 2009