

## No signal from Digital I/O Module

Keywords / Key Phrases: no signal, digital i/o

In the event when there is no signal from the Digital I/O Module, please make sure the option "Digital Output Only" is checked under Master Control in the Surround Mixer settings. Kindly check if there is a red light emitting from the Digital I/O Module optical, that indicates that it is working properly.

### Further Suggestions

[SID 5764](#) - General Information on Digital Output

Last updated: August 11th, 2009