

Connecting Audio Output from a TV with our Sound Card

Keywords / Key Phrases: audio output, TV, TV audio output

To connect the television output to your sound card, you will need to use the Mini Plug to Dual RCA cable (see image below). The audio signal will be taken from the audio "line out" connector on the back of the television. Most of these audio outputs use a connector called "RCA" jack. To connect the television to the sound card, you will use the Mini Plug to Dual RCA cable which goes to the audio input (Line in) of your sound card.



Mini plug to dual RCA Cable: 3.5mm stereo mini phone plug to dual RCA jack stereo cable

Please ensure that the Line-In option in the Creative mixer is selected and not muted.

1. Sound Blaster X-Fi Series: Flexi Jack Mode of Digital I/O panel
2. Sound Blaster Audigy Series: Surround Mixer