

## **No Sound from Optical Output**

Keywords / Key Phrases: no sound from optical output

If the sound card is not producing sound from the DVD system after a settings change, please refer to the option for the Digital Output Sampling Rate. Click on the Digital I/O in the Entertainment Mode to select a lower sampling rate.

Last updated: July 02, 2010