

Intermittent Audio While Streaming Video/Audio

Keywords / Key Phrases: intermittent audio while streaming, streaming issue, intermittent sound, live streaming

Slow internet connection speed or downloading of large contents from the internet will result with occasional stop/hang or restart of streaming video or audio. This may be a result of network unable to handle all of the streaming data as fast as necessary or as require. In these cases, you will usually see a "buffering" message in your player.

If you are getting sounds from other sources like MP3 songs, Videos from DVD, you may want to check the system requirements for the streaming software you are currently using. (eg. Flash Player, Shockwave, etc...)

If the issue still persists, please provide us with the below information to facilitate us with the troubleshooting.

- Are you getting audio output while playing back Media files (MP3, WMA and Etc)?
- What software are you using to playback the streaming audio/radio/video?
- What is the latest ActiveX player and plug-in that are installed in your computer for media streaming?

Last updated: July 06, 2012