

## **Maximum Volume from Sound Card still too Low**

Keywords / Key Phrases: low volume, maximum

Please ensure that you have turned up the volumes to their maximum levels. Check this through the following:

1. Use the Microsoft Volume Control to set all playback levels to the maximum.
2. On the software of the audio playback, turn up the volume control integrated in the software to the maximum.

You should have set the volume to the maximum and if you need to get a louder volume from the sound card, please adjust the volume further from the amplifier or speakers system.

Last updated: July 16th, 2009