

Connecting CD/DVD Optical Drive to X-Fi Sound Card

Keywords / Key Phrases: cd dvd connection to xfi, enable digital CD playback

It is not required to connect the audio cable to your X-Fi sound card for digital playback as you can configure it on your computer by following the instructions below:

1. Click **Start, Settings** then **Control Panel** or **Start, Control Panel**.
2. In the **Control Panel** dialog box, double-click the **System** icon.
3. In the **System Properties** dialog box, click the **Hardware** tab.
4. Click the **Device Manager** button.
5. Double-click the **DVD/CD-ROM** drives icon, and your computer drives appear.
6. Right-click the disk drive icon. A menu appears.
7. Click **Properties**.
8. In the **Digital CD Playback** box of the next dialog box, click the **Enable digital CD audio for this CD-ROM device** check box to select it.

Last updated: July 21th, 2009