


Muting Speakers when using Headphones


Keywords / Key Phrases:mute, muting speaker, headphone

To mute the speakers when the headphone is connected to the headphone jack, ensure that you have checked “Automatically mute speakers”.

Click on **Start, All Programs, Creative** then **Sound Blaster X-Fi** and on **Creative Audio Console**.



In Windows 7, it is called **Audio Control Panel**.



1. Click the **Headphone Detection** tab.
2. **Automatically enable headphone settings.** The speaker settings are automatically enabled for headphones when they are connected and defaults to the original setting when disconnected.
3. **Automatically mute speakers** will mute the speakers as soon as the headphones are connected.

This option is only available for our Titanium Champion series. As the headphone jack for these models are on the front panel, this does not affect the line out for speakers. Hence, the speakers and headphone jacks can simultaneously work if the options to automatically mute the sounds are being unchecked.

Last updated: January 25, 2011