

Applications not found, missing

Keywords / Key Phrases: applications not found, missing apps

After successful installation of the applications from your installation CD, the applications are installed on C:\ drive* of your computer, you can find it in Program Files folder, under the subfolder Creative. You should be able to find the applications for your soundcard there.

If applications are still missing, you need to install the applications again. Please refer to the steps available in [SID 42331: Installing Sound Blaster Drivers and Applications](#)

*Based on default installation.

Last updated: December 8th, 2009